



CM8420-LoVo

Technische Daten

| | |
|--|--|
| Anzahl SMI-Kanäle | 1 |
| Anzahl Antriebe pro Kanal | 16 |
| Einzeladressierung | ja |
| max. Anzahl Antriebe pro Kanal | 16 |
| SMI-Antriebe | SMILoVo |
| Versorgungsspannung | 24 VDC, +-10%, min:0,25W; max:0,72W |
| automatische Adressierung | no |
| Adressierung nach Austausch eines Antriebs | no |
| Zertifikat | Z2203-1 |

Spezielle Funktionen

| | |
|-----------------|--|
| Funktionen: | <ul style="list-style-type: none"> • Ein Kommando für Anfahren von Position und Rotation • Ein Kommando zum Lesen von Position, Rotation und Status • 8 LED rot, grün, orange frei programmierbar |
| Inbetriebnahme: | • |

CM8420-LoVo

Specifications

| | |
|---|--|
| Number of SMI channels | 1 |
| Number of drives per channel | 16 |
| Addressing of single drives | yes |
| Max. number of drives per channel | 16 |
| SMI drives | SMILoVo |
| Power supply voltage | 24 VDC, +-10%, min:0,25W; max:0,72W |
| Automatic addressing | no |
| Addressing after change of a single drive | no |
| Certificate | Z2203-1 |

Special Functions

| | |
|----------------|---|
| Functionality: | <ul style="list-style-type: none"> • Single command for setting of position and rotation • Single command for reading of position, rotation and state • 8 LEDs red, green, orange, freely programmable |
| Commissioning: | • |

Links

Neuberger Gebäudeautomation GmbH
Datenblatt, Installationsanleitung, Anwendungen usw.:
Data sheet, installation manual, application etc.:

www.neuberger.net/
<https://www.neuberger.net/>
<https://www.neuberger.net/>

SMI Standard Motor Interface e.V. :
Anschlussschema Motor / Wiring Diagram Motor, Software SMI-EasyMonitor

www.Standard-Motor-Interface.com